

# QUICK TIPS GUIDE

Thank you for choosing the SHG S D200 DECT Cordless PTT (Push-To-Talk) Headset Adapter

To help you get the best performance from your system, we've included a few quick tips and product highlights. Please review the information below before your first use.

## SHG S D200 DECT Cordless PTT (Push-To-Talk) Headset Adapter



### INITIAL CHARGING

1. Plug in the base unit and allow a minimum of \*\*3 hours of charging time\*\* before first use.
2. Ensure the remote pistol grip and batteries are fully charged for optimal performance.

### BATTERY STATUS INDICATORS

Battery status is indicated by LED lights, blink counts, and audible beep tones:

Battery Level	LED Color	Blink Count
Low	Red	3 Blink
Medium	Yellow	2 Blinks
High	Green	1 Blink

### BATTERY LEVEL INDICATIONS OCCUR:

1. During power-up (initial battery status check).
2. When the remote is placed in the charging cradle.

### LIVE BATTERY SWAP

The SHG Wireless Base Unit supports live battery replacement without disconnecting an active call.

- Replace the battery with the spare battery within 20 – 30 seconds.
- The call will remain active and connected during the battery swap process.

**Important:** Once a battery swap is initiated, you have approximately 20–30 seconds to complete the replacement before system operation may be interrupted.

### FEATURES MANAGEMENT APP:

The following link allows you to access the features management app to fine tune the features of the wireless base unit.

<https://shgptw200-setup.secure-headsets.com/>

**Note:** This application is intended to be installed on an administrator's or supervisor's computer.

### NEED ASSISTANCE?

Refer to the full user manual for detailed operating instructions and troubleshooting information.

Thank you for choosing SHG!

